

How to top up screenwash correctly



1. Choose the right screenwash

- Use a premium concentrated or ready-to-use screenwash
- If concentrated, mix to the correct seasonal ratio
- Use a funnel to avoid spills and waste

Supplied nationwide by
FLEETMAXX
SOLUTIONS



2. Lift the bonnet

- Open the bonnet safely
- Locate the blue screenwash cap with the windscreen symbol
- Flip the cap open and keep it clear



3. Top up the reservoir

- Pour screenwash slowly until the reservoir is full
- Allow bubbles to settle before checking the level

- ✓ Screenwash topped up
- ✓ Visibility restored
- ✓ Ready for the road



How to adjust screenwash nozzles



1. Clear blockages

- Insert a needle gently into the washer nozzle
- Remove dirt and debris blocking the spray



2. Align the nozzle

- Adjust the nozzle so spray hits the centre of the windscreen
- Remove the needle and test the washers
- Repeat until coverage is correct



Why use premium screenwash

- Improves visibility in all weather
- Helps prevent smearing and residue
- Safer driving for cars, vans, and fleets
- Reduces dirt, salt, and insects



Premium screenwash supplied across the United Kingdom



01367 704 910



Complete our enquiry form



FLEETMAXX
SOLUTIONS
YOUR TRUSTED PARTNER